



**WENZHOU RUNXIN MANUFACTURING MACHINE CO.,LTD**

ADD: Jinger Road, Shatou Group, Linjiang, Lucheng District, Wenzhou, Zhejiang, China

Tel: +86-577-88635628 88630038 Fax: +86-0577-88633258

Http://www.run-xin.com Email:sales@run-xin.com



China Patent No.: ZL02220153.X,  
ZL200720045551.5

## Multi-functional Flow Control Valve for Water Treatment Systems

53550 ( F96B1 )

53650 ( F96B3 )

63550 ( F96A1 )

63650 ( F96A3 )

## User Manual





Please read this manual in details  
before using this valve and keep it properly  
in order to consult in the future

0WRX.466.565

MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3

Before the valve put into use, please fill in the below content so as to help us to refer in the future.

**The Program Type Setting (Operation by professional)**

When all symbols light on, press and hold  and  buttons for 5 seconds to enter the menu of valve model selection. **Please set the program type in accordance with the product type.**

**Softener System Configuration**

Tank Size: Dia. \_\_\_\_\_mm, Height \_\_\_\_\_mm;

Resin Volume \_\_\_\_\_L; Brine Tank Capacity \_\_\_\_\_L;

Hardness of Raw Water \_\_\_\_\_mmol/L;

Pressure of Inlet Water \_\_\_\_\_MPa;

Control Valve Model \_\_\_\_\_; Number \_\_\_\_\_;

Specification of Drain Line Flow Control \_\_\_\_\_;

Injector No. \_\_\_\_\_;

Water Source: Ground-water ☐ Filtered Ground-water ☐ Tap Water ☐ Other \_\_\_\_\_.

**Parameter Set**

Parameter	Unit	Factory Default	Actual Value
Time of day	H:m	Current Time	
Control Mode A-01/02 (F96A3/F96B3)	/	A-01	
Water Treatment Capacity (F96A3/F96B3)	m <sup>3</sup>	400.0	
Operation Days (F96A1/F96B1)	D.	03	
Regeneration Time	/	02:00	
Backwash Time	min:sec.	10:00	
Brine & Slow Rinse Time (F96A1/3)	min:sec.	60:00	
Brine Refill Time (F96A1/3)	min:sec.	05:00	
Fast Rinse Time	min:sec.	10:00	
Interval Regeneration Days (F96A3/F96B3)	D.	30	
Output Mode b-01(02)	/	b-01	
K Value (Only for Meter Type)	/	4.194	

● If there is no special requirement when product purchase, we choose 4# drain line flow control (With five pieces of φ8.5 holes) and 4# injector (7804) for the standard configuration for 63550 and 63650.

## Catalogue

Notice.....	3
1.Product Overview.....	4
1.1.Main Application & Applicability.....	4
1.2.Product Characteristics.....	4
1.3.Service Condition.....	6
1.4.Product Structure and Technical Parameters.....	7
1.5. Installation.....	8
2.Basic Setting & Usage.....	15
2.1.The Function of PC Board.....	15
2.2.Basic Setting & Usage.....	16
3.Applications.....	19
3.1.Flow Chart.....	19
3.2.The Function and Connection of PC Board.....	20
A. Signal Output Connector.....	21
B. Interlock.....	24
C. Pressure Relief Connector.....	24
D. Remote Handling Connector.....	24
E. Interlock system.....	25
F. Series System.....	25
3.3.System Configuration and Flow Rate Curve.....	26
3.4.Parameter Settlement.....	28
3.5.Parameter Enquiry and Setting.....	29
3.6.Trial Running.....	33
3.7.Trouble-Shooting.....	34
3.8.Assembly & Parts.....	39
4.Warranty Card.....	46

## Notice

- To ensure normal operation of the valve, please consult with professional installation or repairing personnel before use it.
- If there are any of pipeline engineering and electric works, there must be finished by professional at the time of installation.
- Do not use the control valve with the water that is unsafe or unknown quality.
- Depending on the changing of working environment and water requirement, each parameter of softener should be adjusted accordingly.
- When the water treatment capacity is too low, please check the resin. If the reason is shortage of resin, please add; if the resin is turn to reddish brown or broken, please replace.
- Test water periodically to verify that system is performing satisfactorily.
- Ensure that there is solid salt all the time in the brine tank in the course of using, when this valve is used for softening. The brine tank should be added the clean water softening salts only, at least 99.5% pure, forbidding use the small salt.
- Do not put the valve near the hot resource, high humidity, corrosive, intense magnetic field or intense vibrations environment. And do not leave it outside.
- Forbidden to carry the injector body. Avoid to use injector body as support to carry the system.
- Forbidden to use the brine tube or other connectors as support to carry the system.
- Please use this product under the water temperature between 5 ~ 50℃, water pressure 0.2 ~ 0.6MPa. Failure to use this product under such conditions voids the warranty.
- If the water pressure exceeds 0.6Mpa, a pressure reducing valve must be installed before the water inlet. While, if the water pressure under 0.2MPa, a booster pump must be installed before the water inlet.
- It is suggested to install PPR pipe, corrugated pipe or UPVC pipe, instead of TTSLG pipe.
- Do not let children touch or play, because carelessness operating may cause the procedure changed.
- When the attached cables of this product and transformer are changed, they must be changed to the one that is from our factory.

## 1. Product Overview

### 1.1. Main Application & Applicability

Used for softening, demineralization or filtration water treatment systems

53550/53650 (Filter)

Suit for swimming pool filter equipment

Filtration equipment

RO pretreatment active carbon and sand filtration system

63550/63650 (Down-flow softener regeneration)

Suit for the ion exchange equipment which hardness of the raw water  $\leq 6.5\text{mmol/L}$

Boiler softening water system

RO pretreatment softening system

### 1.2. Product Characteristics

#### ● Simple structure and reliable sealing

The distribution valve adopts hermetic head faces with high degree pottery and corrosion resistance for opening and closing. It combines with Service, Backwash, Brine&Slow Rinse, Brine Refill and Fast Rinse.

#### ● No water pass the valve in regeneration in single tank type.

#### ● Brine refill is controlled by electric ball valve.

Brine refill is controlled by electric ball valve, refilled when in service, shorten the regeneration time.

Brine refill is at the same time of Service, for fixed bed, the water for brine refill is hard water.

#### ● Fixed bed softener could be converted to filter system.

Block the brine line connector of 63550/63650, remove the drain connector, the valve could be converted to filter system.

#### ● Manual function

Realize regeneration immediately by pushing " " at any time.

#### ● Long outage indicator

If outage overrides 3days, the time of day indicator "12:12" will flash to remind people to reset new time of day. The other set parameters do not need to reset. The process will continue to work after power on.

#### ● LED dynamic screen display

The stripe on dynamic screen flash, it indicates the control valve is in service, otherwise, it is in regeneration cycle.

#### ● Buttons lock

No operations to buttons on the controller within 1 minute, button lock indicator light on which represent buttons are locked. Before operation press and hold " " and " " buttons for 5 seconds to unlock. This function can avoid incorrect operation.

#### ● It can choose time clock type or meter type by program selection

When all symbols light on, press and hold " " and " " buttons more than 2 seconds to enter the menu of valve model selection. Press " " and " " buttons to select the requested model, then press " " button to save the selection. Reconnect the power, the model will be showed on display board.


#### ● Interlock function

It has a function of interlock to realize only one valve in regeneration but the other valves are in service while several valves parallel in system. In multi-steps treatment systems such as RO pre-treatment, when several valves are in series, there is only one valve in regeneration or washing to ensure pass water all the times while different valves in regeneration or washing. (Application refer to Figure 3-9)


#### ● Control Signal Output (Only for 63650/63550)

There is a signal output connector on main control board. It is for controlling external wiring (Refer to Figure from Figure3-1 to Figure 3-8).

There are two kinds of output modes: b-01 Mode: Turn on start of regeneration and shut off end of regeneration; b-02 Mode: Signal available only intervals of regeneration cycles and In service.



b-01



b-02

#### ● Remote handling input

This connector can receive external signal, used together with PLC, and computer etc. to control the valve. (Application refer to Figure3-11)

#### ● Pressure relief output

The valve will cut off feeding water to drain line when it switches in regeneration cycles (Same as signal output b-02). Thus in some water treatment system, e.g. Deep Well, one booster pump was installed on the inlet to increase the system water feeding pressure,

MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3

this cut-off will cause pressure on inlet rising too fast to damage the valve. Pressure Relief Output can be used to avoid this problem. (Application refer to Figure3-10)

● **All parameters can be modified**

According to the water quality and usage, the parameters in the process can be adjusted.

● **Two meter types for optional (Suit for 63650/53650)**

Model	Name	Instruction
A-01	Meter Delayed	Regenerate on the day although the available volume of treated water drops to zero (0). Regeneration starts at the regeneration time.
A-02	Meter Immediate	Regenerate immediately when the available volume of treated water drops to zero(0).

● **Maximum interval regeneration days ( Suit for 53650/63650 )**

Under the situation of service reaching the setting days and the volume not yet, it could enter into regeneration process forcibly when current time is the same as regeneration time.

**1.3. Service Condition**

This Valve should be used under the below conditions:

Items		Requirement
Working conditions	Water pressure	0.2MPa ~ 0.6MPa
	Water temperature	5℃ ~ 50℃
Working environment	Environment temperature	5℃ ~ 50℃
	Relative humidity	≤95% ( 25℃ )
	Electrical facility	AC100 ~ 240V/50 ~ 60Hz
Inlet water quality	Water turbidity	Down-flow regeneration (63550/63650) < 5FTU Filter (53550/53650 < 20FTU)
	Water hardness	First Grade Na' < 6.5mmol/L; Second Grade Na' < 10mmol/L
	Free chlorine	< 0.1mg/L
	Iron <sup>2+</sup>	< 0.3mg/L
	(CODMn) CODMn	< 2mg/L ( O <sub>2</sub> )

In the above table, First Grade Na' represents First Grade Na' Exchanger. Second Grade Na' represents Second Grade Na' Exchanger.

● When the water turbidity exceeds the conditions, a filter should be installed on the

MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3


inlet of control valve.

● When the water hardness exceeds the conditions, the outlet water hardness will hardly reach the requirement of boiler feed water (0.03 mmol/L) . It is suggested to adopt second grade softener.


**1.4. Product Structure and Technical Parameters**

A. The appearance is just for reference. It is subjected to the real product.

53550/F96B1



63550/F96A1



MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3

Model	A (mm) max	B (mm) max	H (mm) max
53550/F96B1	658	695	707
63550/F96A1	658	695	870

Remark: If 53550/F96B1 and 63550/F96A1 are installed a flow meter on outlet, then they will be the structure drawings of 53650/F96B3 and 63650/F96A3.

#### B. Technical parameter

The suitable output of transformer for control valve: DC12V, 4.0A

Model	Connect Size					Flow Rate m <sup>3</sup> /h @0.2MPa	Regeneration Mode	Remark
	Inlet/ Outlet	Drain	Brine Line Connector	Regeneration Connector	Top and Bottom Strainer			
53550	DN80	DN80	/	/	DN100	40	By days	Filter
53650							By meter	
63550	DN80	DN80	3/4" M	/	DN100	50	By days	Down-flow regeneration
63650							By meter	

Note: DN80—Outer diameter is  $\phi 90$  UPVC pipeline.

DN100—Outer diameter is  $\phi 110$  UPVC pipeline.

### 1.5. Installation

#### A. Installation notice

Before installation, read all those instructions completely. Then obtain all materials and tools needed for installation.

The installation of product, pipes and circuits, should be accomplished by professional to ensure the product can operate normally.

Perform installation according to the relative pipeline regulations and the specification of Water Inlet, Water Outlet, Drain Outlet, Brine Line Connector.

#### B. Device location

- ① The filter or softener should be located close to drain.
- ② Ensure the unit is installed in enough space for operating and maintenance.
- ③ Brine tank need to be close to softener.
- ④ The unit should be kept away the heater, and not be exposed outdoor. Sunshine or rain will cause the system damage.
- ⑤ Please avoid to install the system in one Acid/Alkaline, Magnetic or strong vibration circumstance, because above factors will cause the system disorder.
- ⑥ Do not install the filter or softener, drain pipeline in circumstance which temperature may drop below 5°C, or above 45°C.

MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3

⑦ One place is recommended to install the system which cause the minimum loss in case of water leaking.

#### C. Support installation

Take out 8 pieces of support and door mats, install them according to the figure 1-1. (The parts description please refers to 5040009 support structure on page 45.)




Figure 1-1

#### D. Pipeline installation, take 63650 as example

##### ① Install control valve

- a. As the Figure 1-2 shows, insert the riser pipe to the bottom strainer and put it into the bottom of the tank.
- b. Fill the mineral to the tank, and the height is accordance with the design code. Assemble the top strainer.
- c. Connect the control valve and support with screw.
- d. Choose the suitable position to install the valve. Using DN100(Outer diameter is  $\phi 110$ ) UPVC pipe to connect top and bottom strainer connector with tank's top and bottom strainer.

Figure 1-2

**Notice:**

- Avoid floccules substance together with resin to fill in the mineral tank.
- Piping installation should be straight, and shall not make control valves or the fittings by torsion.

**② Install flow meter and the inlet/outlet pipeline****A. Install flow meter****Safe notice:**

- A. Before installation, make sure there is no pressure in pipeline and check if pressure released completely.
- B. Before installation, make sure the tested liquid won't make corrosion for the probe. (The testing subject of the probe is water)
- C. Before installation, make sure the temperature and pressure is comply with the probe's requirement. (The temperature of the liquid:  $5\sim 50^{\circ}\text{C}$ ; Testing pressure:  $\leq 0.6\text{MPa}$ )
- D. Before installation, make sure the flow rate of the liquid won't exceed the probe's range. (Testing range:  $1\sim 5\text{m/s}$ ).

- E. Before installation, don't change the probe's shape structure and testing way.
- F. Probe wiring couldn't connect with the transformer which has strong electric or voltage bigger than 12V. Otherwise, it will burn the electric board.

**Probe test position choosing:**

- A. The measure distance of tangential path behind flange should comply with 10 times front and 5 times back of pipeline diameter.
- B. The measure distance of tangential path behind reducer (Only allow turn big to small, but not in reverse) should comply with 15 times front and 5 times back of pipeline diameter.
- C. The measure distance of tangential path behind first class aqual elbow should comply with 20 times front and 5 back of pipeline diameter.
- D. The measure distance of tangential path behind coplanar second class continuous equal elbow should comply with 25 times front and 5 times back of pipeline diameter.
- E. The measure distance of tangential path behind non-coplanar second class continuous equal elbow should comply with 40 times front and 5 times back of pipeline diameter.
- F. The measure distance of tangential path behind valve should comply with 50 times front and 5 times back of pipeline diameter.
- G. Suggest that install probe perpendicularly by pipeline, shouldn't be installed in the bottom of pipeline.
- H. Probe can be installed in perpendicular pipeline which is upward flow direction, but also shall meet the above line requirement.
- I. Probe can not be installed in perpendicular pipeline which is downward flow direction.
- J. The water in tested pipeline should be full. Make sure no air in the pipeline.

**Repair and maintenance of flow meter:**

- A. Before the installation of probe need confirm the impeller in free rotating, there is no obvious block phenomenon.
- B. When the flow meter stop measuring but the tested liquid still flow, it can check the work mode of probe online. Screw the probe nut A out, and check the working condition of the diode on the back of probe. If the diode always light on or off, it indicates the impeller in pipeline stop rotating. It shall stop pipeline working, release pressure in pipeline, and disassemble the probe to check if there is any foreign matter impact impeller rotating. After cleaning, if it can rotate normally by manually, and the diode works normally, it can continue to use after confirming the installation correct.
- C. If the probe has impeller broken, the top bracket of probe damaged, bearing bended, after repairing but still unable to free rotation, or the wetted part has corrosion, or the installation screw thread serious damaged, it shall replace a new probe.

D. If the diode on the back of probe work normally, but the display board show incorrect, please check if the probe wire has any damage and use a multi-meter to check the voltage between shielding and black wire if normally. If the diode light on, there is no voltage output, and if the diode light off, there is voltage output.  
E. As the staining in liquid may cause impeller rotation not smooth, it may affect the measurement accuracy of probe. Therefore, it shall inspect and clean the impeller of probe periodically.




Figure 1-3

- a. As figure 1-2, install a disc filter on the inlet of the filter.
- b. Install valve A, valve B and valve C on the inlet, outlet and the middle of the pipeline of inlet and outlet.
- c. Glue the inlet of the system with the inlet of the valve with DN80 UPVC pipeline (The outer diameter is  $\varnothing 90$ ); Glue the flow meter with outlet of the valve with DN80 UPVC pipeline (The outer diameter is  $\varnothing 90$ ); Glue the outlet of the system with flow meter with DN80 UPVC pipeline (The outer diameter is  $\varnothing 90$ ).
- d. Disassemble the front cover of the valve, connect the flow meter to the flow meter connector of the main control board.(Refer P20 main control board figure)

Notice:

- If making a soldered copper installation, do all sweat soldering before connecting pipes to the valve. Torch heat will damage plastic parts.
- When turning threaded pipe fittings onto plastic fitting, use care not to cross thread or broken valve.
- Inlet pipeline should be in parallel with outlet pipeline. Support inlet and outlet pipeline with fixed holder.
- If the valve belongs to time clock type, there are no flow meter installation step.

③ Install drain pipeline (If no special request, the injector is 7804)

- a. According to P28, for 63550 and 63650, if the diameter of the tank is 1500mm, please

do as step e; if the diameter of the tank is 1800mm, please do as following:

- b. According to P32, match the drain line flow control based on the number and size of the hole.
- c. Use the white manual handle as figure 1-4 shows to open the drain connector, take out the drain line flow control, change it to the suitable one. (Please refer the hole of P28)




Figure 1-4

- d. Tight the drain connector with the drain of the valve.
- e. Use DN80 (Outer diameter is  $\varnothing 90$ ) UPVC pipeline stick to the drain, drain pipeline should directly to the sewer, the sewer and the drain pipeline should installed as figure 1-5.



Figure 1-5

- f. For 53550 and 53650 filter valve, there is no drain line flow control, please do as step c.
- Notice:



● Leave a certain space between the drain pipe and the sewer, avoid wastewater be absorbing to the water treatment equipment.

● The drain pipeline shouldn't be too long, and the drain should no more higher than the valve. For softener, drain pipeline should no longer than 5m; For filter, it should no longer than 2m. If the drain pipeline is longer or higher than the requirement, please disassemble the connector between distribution valve and drain and let the drain of distribution valve connect with the air. Use G1/2 female screw to block the G1/2 male of drain. Please refer the figure 1-6.



Figure 1-6

#### ④ Connect brine tube

a. As figure 1-2 shows, use DN20 UPVC pipeline and other pipeline to connect the brine valve and the brine line connector of the valve.


Notice

● The brine pipeline should as shorter as possible, and smooth. There are less four elbows in the pipeline, or it will make the brine sucking unsmooth.

● It must install brine valve in the brine tank.

## 2. Basic Setting & Usage

### 2.1. The Function of PC Board



#### A. ⌚ Time of day indicator

● ⌚ Light on, display the time of day.

#### B. 🔒 Button lock indicator

● 🔒 Light on, indicate the buttons are locked. At this moment, press any single button will not work (No operation in one minute, 🔒 will light on and lock the buttons.)

● Solution: Press and hold both ⏏ and ⏏ for 5 seconds until the 🔒 light off.

#### C. ⌚ Program mode indicator

● ⌚ Light on, enter program display mode. Use ⏏ or ⏏ to view all values.

● ⌚ Flash, enter program set mode. Press ⏏ or ⏏ to adjust values.

#### D. ⏏ Menu/Confirm button




● Press ⏏, ⌚ light on, enter program display mode and use ⏏ or ⏏ to view all values.

● In program display mode, press ⏏, ⌚ flash, enter program set mode, press ⏏ or ⏏ and adjust values.



● Press ⏏ after all program are set, and then the voice "Di" means all setting are


success and return program display mode.

#### E. Manual/Return button

● Press  in any status, it can proceed to next step.(Example: If outlet water is unqualified, press  in Service status, it will start regeneration cycles instantly; Press  while it is in



Backwash status, it will end backwash and go to Brine & Slow Rinse at once.)

● Press  in program display mode, and it will return in Service; Press  in program set mode, and it will return program display mode.

● Press  while adjusting the value, then it will return program display mode directly without saving value.

#### F. Down and Up







● In program display mode, press  or  to view all values.



● In program set mode, press  or  to adjust values.

● Press and hold both  and  for 5 seconds to lift the Button Lock status.


## 2.2. Basic Setting & Usage

### A. Parameter specification (Take 63650/63550 as example.)

Function	Indicator	Factory Default	Parameter Set Range	Instruction
Time of Day		Random	00:00 ~ 23:59	Set the time of day when use; ":" flash.
Control Mode	A-01	A-01	A-01	Meter Delayed: Regenerate on the day although the available volume of treated water drops to zero (0). Regeneration starts at the regeneration time.
			A-02	Meter Immediate: Regenerate immediately when the available volume of treated water drops to zero(0).
Service Days		1-03D	0 ~ 99Days	Only for Time Clock Type, regeneration by days.
Regeneration Time		02:00	00:00 ~ 23:59	Regeneration time; ":" light on.
Water Treatment Capacity		400.0m <sup>3</sup>	0 ~ 9999.99 m <sup>3</sup>	Water treatment capacity in one circle (m <sup>3</sup> )
Backwash Time		10:00	0 ~ 99 : 59	Backwash time(Minute:Second)
Brine & Slow Rinse Time		60:00	0 ~ 99 : 59	Brine & Slow Rinse time(Minute:Second)

Fast Rinse Time		10:00	0 ~ 99 : 59	Fast rinse time(Minute:Second)
Brine Refill Time		05:00	0 ~ 99 : 59	Brine refill time(Minute)
Maximum Interval Regeneration Days	H-30	30	0 ~ 40	Regenerate on the day even through the available volume of treated water do not drop to zero (0).
Output Control Mode	b-01	01	01 or 02	Mode 01: Signal turn on start of regeneration and shut off end of regeneration. (Connection refer to the Figure P5) Mode 02: Signal available only intervals of regeneration cycles and in service. (Connection refer to the Figure P5)

### B. Process Display (Take 63650 A-01 as example)



#### Illustration:

- In Service status, the figure shows A/B/C/D; In Backwash status, it shows figure E/C; In Brine & Slow Rinse status, it shows F/C; In Fast Rinse status, it shows figure G/C; In Brine Refill status, it shows figure H/C. In each status, every figure shows 15 seconds.
- Above displays are taking 63650 for example. For the Time Clock Type, it shows the rest days, such as 1-03D.
- The display screen will only show "-00-" when the electrical motor is running.
- The time of day figure"" flash continuously, such as "12: 12" flash, indicates long outage of power. It reminds to reset the time of day.
- The display will show the error code, such as "-E1-" when the system is in error.
- Working process: Service → Backwash → Brine & Slow Rinse → Fast Rinse → Brine Refill → Service

### C. Usage

After being accomplished installation, parameter setting and trail running, the valve could be put into use. In order to ensure the quality of outlet water can reach the requirement, the user should complete the below woks:

①Ensure that there is solid salt all the time in the brine tank in the course of using when this valve is used for softening. The brine tank should be added the clean water softening salts only, at least 99.5% pure, forbidding use the small salt and iodized salt.

②Test the outlet water and raw water hardness at regular time. When the outlet water hardness is unqualified, please press the and the valve will temporary regenerate again ( It will not affect the original set operation cycle).

③When the feed water hardness change a lot, you can adjust the water treatment capacity as follow:

Press and hold both and for 5 seconds to lift the lock status. Press , and the light on, then press to choose the water treatment capacity. The digital area will show the given water treatment capacity. Press again, the water treatment capacity value flash, then press to reset the value. Press twice and hear a sound "Di", then finish the adjustment. Press exit and turn back to the service status.


④For A-01 control mode (Delayed regeneration type), please pay attention whether the time is current or not. If the time is not right, you can adjust as below: After lifting the lock status, press , the and light on. Then press , the and hour value flash. Press or continuously to reset the hour value; Press again, and minute value flash. Press or continuously, reset the minute value; Press and hear a sound "Di", then finish the adjustment. Press exit and turn back to the service status.

The regeneration parameters have been set when control valve left the factory. Generally, it does not need resetting. If you want to inquire and modify the settings, you can refer to the professional application specifications.

## 3. Applications

### 3.1. Softener and Filter Flow Chart

A. Down-flow/Up-flow regeneration softener valve (63550/63650) and filter valve (53550/53650) flow chart:




Note:

- For 53550/53650 filter valve, only has service status, backwash status and fast rinse status.
- Brine refill is at the same time of service. When brine refill starts, the ball valve is opened, while it finishes, the ball valve closed.

Note: Brine refill is at the same time of service. When brine refill, water is refilled to brine tank through top strainer, ball valve is opened. When brine refill finishes, ball valve is closed.

### 3.2. The Function and Connection of PC Board

Open the front cover of control valve, you will see the main control board and connection port as below:



The main functions on main control board:

Function	Application	Explanation
Signal output connector b-01	Outlet solenoid valve	If system strictly require no hard water flow from outlet or controlling the liquid level in water tank.
	Inlet pump	Increase pressure for regeneration or washing. Use the liquid level controller to control inlet pump to ensure there is water in tank.
Signal output connector b-02	Inlet solenoid valve or inlet pump	When inlet pressure is high, it needs to close water inlet when valve is rotating to protect motor.
Pressure relief connector	Control the inlet bypass to release pressure	When valve is rotating, pressure relief connector opened to prevent pressure increasing rapidly.
Interlock connector	To ensure only one control valve regeneration or washing in system.	Use in RO Pre-treatment, water supply together but regeneration in turn. Second grade ion exchange equipment, etc.
Remote handling connector	Receipt signal to make the control rotate to next circle	It is used for on-line inspection system, PC connection, and realize automatically or remote controlling valve.

### A. Signal Output Connector

#### 1) Control Solenoid Valve (Set b-01)

##### ①Solenoid Valve on Outlet Controls Water Level in Brine Tank.

**Instruction:** If system strictly require no hard water flow from outlet in regeneration cycle( Mainly for no hard water flow out when valve is switching or valve in backwash or brine drawing positions), a solenoid valve could be installed on outlet, the wiring refer to Figure 3-1.




Figure3-1 Wiring of Solenoid Valve on Outlet

#### Function:

When valve in service status, if soft water tank is short of water, solenoid valve is open to supply soft water, but if water tank has enough water, solenoid valve is closed, so no soft water supplied.

When the valve in backwash status, there is no signal output. So, solenoid valve is closed, and now water flow into soft water tank.

#### ②Solenoid Valve on Inlet (Set b-02)

**Instruction:** When inlet pressure exceeds 0.6MPa, install a solenoid valve on inlet.

Control mode is b-02. Pressure relieved when valve switching, the wiring refer to Figure 3-2. As Figure 3-3 shows, it also can use the pressure relief port to work.




Figure 3-2 Wiring of Solenoid Valve on Inlet




Figure3-3 Wiring of Pressure Relief Port

### Function:

When inlet pressure is high, install a solenoid valve on inlet to ensure valve switching properly. When valve is exactly at position of Service, Backwash, Brine& Slow Rinse, Brine Refill and Fast Rinse, solenoid valve is open. When valve is switching, solenoid valve is closed, no water flow into valve to ensure valve switching properly. It could prevent the problem of mix water and water hammer.

Use interlock cable to realize valves in parallel and series in same system which is suited for RO pretreatment system or second grade Na<sup>+</sup> system. The Wiring refers to Figure 3-4:




Figure 3-4 Wiring of Solenoid Valve in Inlet

### 2) Liquid Level Controller Controls Inlet Pump (Two-phase Motor) (Set b-01)

**Instruction:** For the system using well or middle-tank supplying water, switch of liquid level controller and valve together control pump opening or closing. The wiring refer to Figure 3-5:




Figure 3-5 Wiring of Liquid Level Controller Controlling Inlet Pump

### Function:

When valve in service status, if water tank is short of water, start up pump, but if water tank has enough water, the switch of liquid level controller is closed, so pump doesn't work.

When valve in regeneration cycle, inlet always has water no matter what is water condition in water tank. As Runxin valve no water pass outlet in regeneration cycle, it ensure no water fill into brine tank. A liquid switch at the top of well or in middle water tank RO system protect pump from working without water in case of out of raw water.

### 3) Liquid Level Switch in Water Tank Controls Inlet pump (Three-phase) (Set b-01) (Refer to Figure 3-6)




Figure 3-6 Wiring of Liquid Level Switch in Water Tank Controls Inlet Pump

### 4) Control Inlet Booster Pump (Set b-01 or b-02)

**Instruction:** If inlet water pressure is less than 0.15MPa, which makes backwash or brine difficult, a booster pump is suggested to be installed on inlet. Control mode b-01. When system in regeneration cycle, booster pump is open, the wiring refer to Figure 3-7. If the booster pump current is bigger than 5A, system need to install a contactor, the wiring refer to Figure 3-8




Figure 3-7 Wiring of Booster Pump on Inlet




Figure 3-8 Wiring of Booster Pump on Inlet

## B. Interlock

### Instruction:

In the parallel water treatment system, it ensure only one valve in regeneration or washing cycle and (n-1) valves in service, that is, realizing the function of supplying water simultaneously and regenerating individually

In the series and parallel water treatment system (Second grade Na<sup>+</sup> Exchanger or RO pre-treatment system), it ensure only one valve in regeneration or washing cycle and there is/are water(s) in service. refer to Figure 3-9



Figure 3-9 Network System Wiring with Interlock Cable

### Note:

Use Interlock Cable to connect CN8 to CN7 on next valve in the loop.

One system with several valves, if interlock cable is disconnected, the system is divided into two individual system.

## C. Pressure Relief Output

Runxin valve will cut off feeding water to drain line when it switches in regeneration cycles. Thus in some water treatment system, e.g. Deep Well, one booster pump was installed on the inlet to increase the system water feeding pressure, this cut-off will cause pressure on inlet rising too fast to damage the valve. Pressure Relief Output can be used to avoid this problem. The wiring refer to Figure3-10.




Figure 3-10 Wiring of Pressure Relief Output




Figure 3-11 Wiring of Remote Input

## D. Remote Handling Connector

Used for making pure water, connected with online monitory system or PC machine: when the conductivity or other parameter reach the setting valve or PC machine give the

signal, need regeneration. It can give the signal to the remote handling connector of the main control board to let it regenerate by signal time. The connector receives the signal is same as handle press. The wiring refers to Figure 3-11.

## E. Interlock System

It only needs to connect the 2 or more valve by interlock cable to realize simultaneous water supply and independent regeneration. The wiring refer to Figure3-12.




Figure 3-12 Interlock system




Figure 3-13 Series System

## F. Series System

This is a 2 or more than 2 valves system, all in service, with one flow meter for the entire system. For the time type valve, the regeneration time should be set and adjusted to the Max; for the volume type valve, connect its signal output connector with the remote handle connector of the time-type valve. That can realize the function of supplying water simultaneously and regenerating orderly. The wiring refer to Figure 3-13:

### 3.3. System Configuration and Flow Rate Curve

#### A. Product Configuration

① Product 63550-63650 configuration with tank, resin volume, brine tank and injector.

Tank Size (mm)	Resin Volume (L)	Flow Rate (t/h)	Brine Tank Size (mm)	The Minimum Salt Consumption for Regeneration (Kg)	Injector Model
φ 1500 × 2400	2500	44.0	φ 1240 × 1600	375.00	7804
φ 1800 × 2400	3200	63.0	φ 1360 × 1690	480.00	7805

Note: The flow rate calculation is based on linear velocity 25m/hr; the minimum salt consumption for regeneration calculation is based on salt consumption 150g / L (Resin).



② Product 53550/53650 configuration with tank, filter material.

Tank Size	Volume of Filter Material	Carbon Filter		Sand Filter	
		Filtering Flow Rate	Backwash Flow Rate	Filtering Flow Rate	Backwash Flow Rate
mm	L	m <sup>3</sup> /h	m <sup>3</sup> /h	m <sup>3</sup> /h	m <sup>3</sup> /h
φ 900 × 2400	900	7.6	22.9	15.9	34.3
φ 1000 × 2400	1100	9.5	28.9	19.6	42.4
φ 1200 × 2400	1500	13.5	40.7	28.2	61

Attention: the filtering flow rate of carbon filter is calculated based on the 12m/h operation rate; the backwash flow rate is calculated based on the 10L/(m<sup>2</sup>·s) backwash intensity; the filtering flow rate of sand filter is calculated based on the 25m/h operation rate; the backwash flow rate is calculated based on the 15L/(m<sup>2</sup>·s) backwash intensity.


#### B. Flow Rate characteristic

##### 1). Pressure-flow rate curve









### 3.5.2.K valve setting method

(It is related to flow rate factor. The K valve is opposite of the flow rate factor)

When connect power, press and hold on " Menu / Confirm" button and " Manual / Return" button for 3 seconds, enter into K valve setting interface. Press or button to adjust the valve. Press "Menu/Confirm" button to go back to working interface.

### 3.5.3.Parameter Setting(Take 63650 A-01 as example)

In program display mode, press and enter into program set mode. Press or to adjust the value.

### 3.5.4.The steps of parameter setting

Items	Process steps	Symbol
Time of Day	<p>When time of day "12: 12" continuously flash, it reminds to reset;</p> <p>1. Press  to enter into program display mode; both  and  symbol light on, " : " flash;</p> <p>2. Press , both  and hour value flash, through  or  to adjust the hour value;</p> <p>3. Press  again, both  and minute value flash, through  or  to adjust the minute value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	

Control Mode	<p>1. In control mode display status, press  and enter into program set mode,  and 01 value flash;</p> <p>2. Press  or , set the value to be A-01 or A-02 control mode;</p> <p>3. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	
Regeneration Time	<p>1. In regeneration time display status, it shows 02:00 Press  and enter into program set mode.  And 02 flash;</p> <p>2. Press  or  to adjust the hour value;</p> <p>3. Press  again,  and 00 flash, press  or  to adjust the minute value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	
Water Treatment Capacity	<p>1. In water treatment capacity display status, it shows  and 400.0 Press  and enter into program set mode.  and 400 flash</p> <p>2. Press  or  to adjust the water treatment capacity value (m<sup>3</sup>) ;</p> <p>3. Press , decimal value flash. Press  or  to adjust the decimal value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	
Back wash	<p>1. In backwash time display status, it shows  and 2-10:00. Press  and enter into program set mode.  and 10 flash;</p> <p>2. Press  or  to adjust the backwash minute time ;</p> <p>3. Press , 00 flash. Press  or  to adjust the backwash second value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	

Brine & Slow Rinse	<p>1. In brine&amp; slow rinse time display status, it shows  and 3-60:00. Press  and enter into program set mode.  and 60:00 flash;</p> <p>2. Press  or  to adjust the brine&amp;slow rinse minute time;</p> <p>3. Press , 00 flash. Press  or  to adjust the brine&amp;slow rinse second value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	
Fast Rinse Time	<p>1. In fast rinse time display status, it shows  and 4-10:00. Press  and enter into program set mode.  and 10:00 flash;</p> <p>2. Press  or  to adjust the fast rinse minute time;</p> <p>3. Press , 00 flash. Press  or  to adjust the fast rinse second value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	
Brine Refill Time	<p>1. In brine refill time display status, it shows  and 5-05:00. Press  and enter into program set mode.  and 05:00 flash;</p> <p>2. Press  or  to modify the brine refill minute time;</p> <p>3. Press , 00 flash. Press  or  to adjust the brine refill second value;</p> <p>4. Press  and hear a sound "Di", then finish adjustment, press  to turn back.</p>	
Maximum Interval Regeneration Days	<p>1. In maximum Interval regeneration days display status, it shows H-30. Press  and enter into program set mode.  and 30 flash;</p> <p>2. Press  or  to adjust the Interval regeneration days;</p> <p>3. Press  and finish the adjustment, press  to turn back.</p>	

For example, the fast rinse time of a softener is 12 minutes. After regenerating, the chloridin in the outlet water is always higher than normal, indicating that there is not enough time for fast rinse. If you want the time to set to 15 minutes, the modification steps as follows:





- ① Press and hold both and to lift the button lock statues ( light off ) ;
- ② Press . light on;
- ③ Press or continuously until light on. Then the digital area shows: 4-12:00M;
- ④ Press , and 12 flash;
- ⑤ Press continuously until 12 changed to 15;
- ⑥ Press , there is a sound "Di" and the figure stop flashing; the program back to enquiry status
- ⑦ If you want to adjust other parameters, you can repeat the steps from ② to ⑤; If you don't, press and quit from the enquiry stat, the display will show the current service status.

### 3.6. Trial Running


After installing the multi-functional flow control valve on the resin tank with the connected pipes, as well as setting up the relevant parameter, please conduct the trial running as follows:

- A. Close the inlet valve B & C, and open the bypass valve A. After cleaning the foreign materials in the pipe, close the bypass valve A. (As Figure 1-2 shows)
- B. Fill the brine tank with the planned amount of water and adjust the air check valve. Then add solid salt to the tank and dissolve the salt as much as possible.
- C. Switch on power. Press and go in the Backwash position; when light on, slowly open the inlet valve B to 1/4 position, making the water flow into the resin tank; you can hear the sound of air-out from the drain pipeline. After all air is out of pipeline, then open inlet valve B completely and clean the foreign materials in the resin tank until the outlet water is clean. It will take 8 ~ 10 minutes to finish the whole process.
- D. Press , turning the position from Backwash to Brine& Slow Rinse; light on and enter in the process of Brine& Slow Rinse. The air check valve close when control valve finished sucking brine, then slow rinse start to work. It is about 60 ~ 65minutes for whole process.
- E. Press , turning the position from Slow Rinse to Fast Rinse. light on and start to fast rinse. After 10 ~ 15minutes, take out some outlet water for testing; if the water

hardness reach the requirement, and the chloridion in the water is almost the same compared with the inlet water, then go to the next step.

F. Press  turning the position from Fast Rinse to Brine Refill.  light on (Meanwhile it is in Service status) and it indicates the brine tank is being refilled with water to the required level. It takes about 5 ~ 6 minutes, then add solid salt to the brine tank.  
G. Press , making the control valve return to Service Status;  light on and start to running.

#### Note:

● When the control valve enter into the regeneration status, all program can be finished automatically according to the setting time; if you want one of steps terminated early, you can press .

● If water inflow too fast, the media in tank will be damaged. When water inflow slowly, there is a sound of air emptying from drain pipeline.

● After changing resin, please empty air in the resin according to the above Step C.

● In the process of trial running, please check the water situation in all position, ensuring there are no resin leakage.

● The time for Backwash, Brine & Slow Rinse, Brine Refill and Fast Rinse position can be set and executed according to the calculation in the formula or suggestions from the control valve suppliers.

### 3.7. Trouble-Shooting

#### A. Control Valve Fault

Problem	Cause	Correction
1. Softener fails to regenerate.	A. Electrical service to unit has been interrupted. B. Regeneration cycles set incorrect. C. Controller is defective. D. Motor fails to work.	A. Assure permanent electrical service (Check fuse, plug, pull chain or switch). B. Reset regeneration cycles. C. Replace controller. D. Replace motor.
2. Regeneration time is not correct.	A. Time of Day not set correctly. B. Power failure more Than 3 days.	Check program and reset time of day.

3. Softener supply hard water.	A. Bypass valve is open or leaking. B. No salt in brine tank. C. Injector plugged. D. Insufficient water flowing into brine tank. E. Internal valve leak. F. Regeneration cycles not correct. G. Shortage of resin. H. Raw water quality turns bad or flow meter blocked.	A. Close or repair bypass valve. B. Add salt to brine tank and maintain salt level above water level. C. Change or clean injector. D. Check brine tank refill time. E. Change valve body. F. Set correct regeneration cycles in the program. G. Add resin to mineral tank and check whether resin leaks. H. Reduce the raw water turbidity or clean or replace the flow meter.
4. Softener fails to draw brine.	A. Line pressure is too low. B. Brine line is plugged. C. Brine line is leaking. D. Injector is plugged. E. Internal control leak. F. Drain line is plugged. G. Sizes of injector and DLFC not match with tank. H. Ball valve or cable failure.	A. Increase line pressure. B. Clean brine line. C. Replace brine line. D. Clean or replace new parts. E. Replace valve body. F. Clean drain line flow control. G. Select correct injector size and DLFC according to the P20 requirements. H. Replace ball valve or cable.
5. Unit used too much salt.	A. Improper salt setting. B. Excessive water in brine tank.	A. Check salt usage and salt setting. B. See problem no. 6.
6. Excessive water in brine tank.	A. Overlong refilling time. B. Foreign material in brine line. C. Foreign material in brine valve and plug drain line flow control. D. Not install safety brine valve but power failure while salting. E. Safety brine valve breakdown. F. Ball valve doesn't close completely.	A. Reset correct refilling time. B. Clean brine line. C. Clean brine valve and brine line. D. Stop water supplying and restart power and install safety brine valve in salt tank. E. Repair or replace safety brine valve. F. Repair or replace ball valve.

7. Pressure Lost or iron in conditioned water.	A. Iron in the water supply pipe. B. Iron mass in the softener. C. Fouled resin bed. D. Too much iron in the raw water.	A. Clean the water supply pipe. B. Clean valve and add resin cleaning chemical, increase frequency of regeneration. C. Check backwash, brine draw and brine tank refill. Increase frequency of regeneration and backwash time. D. Iron removal equipment is required to install before softening.
8. Loss of resin through drain line.	A. Air in water system. B. Bottom strainer broken. C. Improperly sized drain line control.	A. Assure that well system has proper Air eliminator control. B. Replace new bottom strainer. C. Check for proper drain rate.
9. Control cycle continuously.	A. Locating signal wiring breakdown. B. Controller is faulty. C. Foreign material stuck the driving gear. D. Time of regeneration steps were set to zero.	A. Check and connect locating signal wiring. B. Replace controller. C. Take out foreign material. D. Check program setting and reset.
10. Drain flows continuously.	A. Internal valve leak. B. When electricity fails to supply, valve stops backwash or fast rinse position.	A. Check and repair valve body or replace it. B. Adjust valve to service position or turn off bypass valve and restart when electricity supply.
11. Interrupted or irregular brine.	A. Water pressure too low or not stable. B. Injector is plugged or faulty. C. Air in resin tank. D. Floccules in resin tank during backwash. E. Strainer is plugged.	A. Increase water pressure. B. Clean or replace injector. C. Check and find the reason. D. Clean the floccules in resin tank. E. Clean the broken resin from strainer.
12. Water flow out from drain or brine pipe after regeneration.	A. Foreign material in valve which makes valve can't be closed completely. B. Hard water mixed in valve body. C. Water pressure is too high which result in valve doesn't get the right position. D. Ball valve is not be closed completely.	A. Clean foreign material in valve body. B. Change valve core or sealing ring. C. Reduce water pressure or use pressure release function. D. Repair or replace the ball valve or the wire.


13. Salt water in soften water.	A. Foreign material in injector or injector fails to work. B. Brine valve cannot be shut-off. C. Time of rapid rinse too short.	A. Clean and repair injector. B. Repair brine valve and clean it. C. Extend rapid rinse time.
14. Unit capacity decreases.	A. Unit fails to regenerate or regenerate not properly. B. Fouled resin bed. C. Salt setting not proper. D. Softener setting not proper. E. Raw water quality deterioration. F. Turbine of flow meter is stuck.	A. Regenerate according to the correct operation requirement. B. Increase backwash flow rate and time, clean or change resin. C. Readjust brine drawing time. D. According to the test of outlet water, recount and reset. E. Regenerate unit by manual temporary, then reset regeneration cycle. F. Disassemble flow meter and clean it or replace a new turbine.

### B. Controller Fault

Problem	Cause	Correction
1. All indicators display on front panel.	A. Wiring of front panel with controller fails to work. B. Control board is faulty. C. Transformer damaged. D. Electrical service not stable. E. Display board is damaged.	A. Check and replace the wiring. B. Replace control board. C. Check and replace transformer. D. Check and adjust electrical service. E. Replace the display board.
2. No display on front panel.	A. Wiring of front panel with controller fails to work. B. Front panel damaged. C. Control board damaged. D. Electricity is interrupted.	A. Check and replace wiring. B. Replace front panel. C. Replace control board. D. Check electricity.
3. E1 Flash	A. Wiring of locating board with controller fails to work. B. Locating board damaged. C. Mechanical driven failure. D. Faulty control board. E. Wiring of motor with controller is fault. F. Motor damaged.	A. Replace wiring. B. Replace locating board. C. Check and repair mechanical part. D. Replace control board. E. Replace wiring. F. Replace motor.
4. E2 Flash	A. Hall component on locating board damaged. B. Wiring of locating board with controller fails to work. C. Control board is faulty.	A. Replace locating board. B. Replace wiring. C. Replace control board.
5. E3 or E4 Flash	A. Control board is faulty.	A. Replace control board.

### 3.8. Assembly & Parts

#### 63650 Structure (Main body part)



**MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3****63650 Valve Body Components and part No.**

Item No.	Description	Part No.	Quantity
1	Air Pipeline Connector	5455001	1
2	Seal Washer	8371011	2
3	Nut	8940005	1
4	Washer	8952003	1
5	Gasket	8156003	1
6	Air Pipeline	8465010	1
7	O-ring	8378218	4
8	Connector	8458081	2
9	Clip	8270011	3
10	O-ring	8378219	3
11	Connector	8458078	1
12	Animated Nut	8947030	3
13	Connector	8458077	2
14	Pipeline	8457025	3
15	Hexagonal Nut	8940016	3
16	Filter	3914001	1
17	Seal Washer	8371021	1
18	Hexagonal Bolt	8909016	4
19	Diaphragm Pump	2976091	1
20	Injector Cover	8315013	1
21	Seal Washer	8371006	1
22	Nozzle	8454025	1
23	O-ring	8378104	1
24	O-ring	8378101	2
25	Injector Body	8008005	1
26	Pressure Gauge Protect Valve	2976013	1

Item No.	Description	Part No.	Quantity
32	Nut	8940006	1
33	Elbow Pipeline	8457072	1
34	O-ring	8378113	1
35	Nut	8940007	1
36	Air Pipeline	8465012	1
37	Hexagonal Bolt Set	5851006	4
38	Seal Washer	8371047	8
39	Pipeline	8457075	1
40	Piston	5450002	1
41	Plug	8323016	4
42	O-ring	8378031	4
43	Cover	8315037	4
44	O-ring	8378214	4
45	Piston	5450001	3
46	Support	5156002	2
47	Hexagonal Bolt Set	5851001	4
48	Hexagonal Nut	8940023	1
49	Fixer	8109053	1
50	Hexagonal Bolt Set	5851009	1
51	O-ring	8378199	3
52	Connector	8458080	3
53	Animated Nut	8947031	3
54	O-ring	8378216	12
55	Corner Valve	3911004.05	1
56	Connector	8458079	3
57	Impeller Set	5295004	1

**MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3**

27	Pressure Gauge	6342001	1
28	Hexagonal Bolt Set	5851005	4
29	Seal Washer	8371019	1
30	Ball Valve	2976064	1
31	Washer	8371001	1

58	Tee Valve	5457026	1
59	Valve Body	5022068	1
60	O-ring	8378217	1
61	Flow Control	8468071	1
62	Air Pipeline	8465013	1


Note:

- For 63550 components, there is no #57 and #58.
- For 53650 components, there is no #9-#11. Change #20-#25, #28-#35 to 1 piece of 8323012 and 2 pieces of 8378101.
- For 53550 components, there is no #57 and #58.

MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3

63650 Distribution valve structure

63650 Distribution valve




MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3

63650 Distribution valve components and part No.

Item No.	Description	Part No.	Quantity
1	Valve Body	8022169	1
2	Hexagonal Bolt	8909016	4
3	Seal Ring	8370031	1
4	Fixed Disk	8469023	1
5	Moving Disk	8459025	1
6	Moving Seal Ring	8370053	1
7	Shaft	8258009	1
8	Anti-friction Washer	8216010	1
9	O-ring	8378078	2
10	O-ring	8378107	1
11	Fitting Nut	8092007	1
12	Locating Board	6380034	1
13	Screw, Cross	8909008	4
14	Gear	5241005	1
15	Screw, Cross	8909013	1
16	Back Cover	8005002	1

Item No.	Description	Part No.	Quantity
17	Label	8865001	1
18	Front Cover	830002.05	1
19	Display Board	6381003	1
20	Wire for Display Board	5512001	1
21	Screw, Cross	8909004	2
22	Wire for Locating Board	5511019	1
23	Main Board	6382057	1
24	Wire Clip	8126014	1
25	Power Wire	5513011	1
26	Small Gear	8241010	1
27	Pin	8993003	1
28	Motor	6158506	1
29	Blind Hole Nut	8940012	1
30	Seal Washer	8371020	1
31	Screw, Cross	8902008	4

5450001 Piston structure




**MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3**

**5040001 Piston components and part No.**

Item No.	Description	Part No.	Quantity	Item No.	Description	Part No.	Quantity
1	Screw,	8909008	3	4	Piston	8450003	1
2	Fitting Nut	8092041	1	5	O-ring	8378216	1
3	Seal Ring	8370094	1	6	O-ring	8378214	2

**5450002 Piston structure**




**5040002 Piston components and part No.**

Item No.	Description	Part No.	Quantity	Item No.	Description	Part No.	Quantity
1	Screw, Cross	8909008	3	5	O-ring	8378110	1
2	Fitting Nut	8092042	1	3	Piston	8450004	1
3	Seal Ring	8370094	2	7	O-ring	8378216	1
4	Bushing	8210005	1	8	O-ring	8378214	1

**MODEL: 53550-F96B1/53650-F96B3/63550-F96A1/63650-F96A3**

**5040009 Support structure**



**5040009 Support components and part No.**

Item No.	Description	Part No.	Quantity
1	Door Mat	8156002	4
2	Screw, Cross M6X25	8902039	8
3	Support	8040030	4
4	Washer	8952007	24
5	Screw, Cross M6X20	8902038	16

Item No.	Description	Part No.	Quantity
6	Support	8040031	4
7	Spring Washer	8953001	24
8	Hexagonal Nut	8940020	24
9	Hexagonal Nut	8940021	4
10	Hexagonal Bolt Set	5851002	4




## 4. Warranty Card

Dear client:

This warranty card is the guarantee proof of RUNXIN brand multi-functional flow control valve. It is kept by client self. You could get the after-sales services from the supplier which is appointed by RUNXIN manufacturer. Please keep it properly. It couldn't be retrieved if lost. It couldn't be repaired free of charge under the below conditions:

1. Guarantee period expired.(One year);
2. Damage resulting from using, maintenance, and keeping that are not in accordance with the instruction.
3. Damage resulting from repairing not by the appointed maintenance personnel.
4. Content in guarantee proof is unconfirmed with the label on the real good or be altered.
5. Damage resulting from force majeure.

Product Name	 Multi-functional Flow Control Valve for Water Treatment Systems			
Model			Code of Valve Body	
Purchase Company Name			Tel/Cel.	
Problem				
Solution				
Date of Repairing		Date of Accomplishment		Maintenance Man Signature

When product need warranty service, please fill in the below content and sent this card together with the product to the appointed suppliers or Runxin company.

End-user Company Name			Tel/Cel.	
Purchase Company Name			Tel/Cel.	
Model			Code of Valve Body	
Tank Size $\Phi$ ×	Resin Tank Size L	Raw Water Hardness	Mmol/L.	
Water Source: Ground-water <input type="checkbox"/> Tap Water <input type="checkbox"/>	Water Treatment Capacity m	Backwash Time	min	
Brine & Slow Rinse Time min	Brine Refill Time min	Fast Rinse Time	min	
Problem Description				